

Making Patterns of Metal, Masonry or Wood Window Wells

Why do I need to make a pattern?

Due to the unusual size or shape of some window wells, it is necessary for us to have a template of the well in order to ensure a proper fit of the Window Bubble. By providing this pattern and photos, we can guarantee the fit of the cover 100% to your well. Please call us if you have any questions about patterns or you do not understand these directions. We would be glad to walk you through the process.

What do I use to make the pattern?

We suggest making this template from cardboard or similar stiff material. This will allow you to get a true tracing of the well. This pattern can be transferred to paper or other material such as wallpaper, newspaper, etc. for ease of mailing. Be sure to transfer all information onto any tracing. We would be glad to provide a pattern kit for you for a fee of \$25.00. This covers the cost of shipping the pattern materials to you and back to our factory once you have traced your well. Please call for details.

How do I make the pattern for Metal Window Wells?

1. Lay the cardboard over the metal well. Be sure the well is covered completely. Immediately mark surface facing up as **TOP**. Also indicate what number well you are tracing. Please use the same numbering as you did when filling out your measuring form or as indicated on your quote.
2. Trace the outside edge of the well onto the underside of the cardboard. If it is easier to trace the inside of the well do so, but be sure to indicate if the tracing is the inside or outside of the well.
3. Indicate on the pattern if there are any pipes or wires entering in or around the well.
4. Please take several photos of the well and return them with the pattern. Photos may also be e-mailed to quotes@windowbubble.com. Document the well number and your contact information in the e-mail.

How do I make the pattern for Masonry or Wood Window Wells?

1. Lay the cardboard over the well top. Be sure the well top is covered completely. Immediately mark surface facing up as **TOP**. Also indicate what number well you are tracing. Please use the same numbering as you did when filling out your measuring form or as indicated on your quote.
2. Trace the outside edge of the well onto the underside of the cardboard. If you need to cut the cardboard closer to the proper shape of the well please do so. If it is easier to trace the inside of the well do so, but be sure to indicate whether the tracing is the inside or outside of the well top. Be sure to mark on the pattern how wide the well top is. This information is critical for us to ensure your cover will fit properly.
3. Indicate on the pattern if there are any pipes or wires entering in or around the well.
4. Please take several photos of the well and return them with the pattern. Photos may also be e-mailed to quotes@windowbubble.com. Document the well number and your contact information in the e-mail.

Dilworth Manufacturing Company
Creators of the Window Bubble®

PO Box 158, Honey Brook, PA 19344-0158

Toll Free Phone: 888-624-8699

Toll Free Fax: 877-859-7226